

Iomega's Klik!™ Mobile Drive



User's Manual for the Klik! Mobile Drive and Klik! Software

- ♦ Klik! Drive for Digital Cameras
- ♦ Klik! Drive for Mobile Computers
- ♦ Klik! Drive Plus

Special Clik! icons have been developed to help you find information about your Clik! Drive in this user manual quickly.



*Clik! Drive for
Digital Cameras*



*Clik! Drive for
Mobile Computers*



Clik! Drive Plus



Caution



Hot Tips



*Charging the
Clik! Battery*



*Connecting the
Clik! Mobile Drive*



*Installing
Software*



Warnings

© Copyright 1998 Iomega Corporation
1821 West Iomega Way
Roy, UT, 84067

Notice: The information contained in this manual is subject to change without notice.

Iomega, the stylized “i” logo, and the swirl and hand graphics are registered trademarks of, and Clik! and the eye graphic are trademarks of, Iomega Corporation. Microsoft, Windows, and Windows NT are registered trademarks of Microsoft Corporation registered in the United States and other countries. All other product and brand names are the property of their respective owners.

Table of Contents

<i>Getting Started</i>	1
Clik! Drive Parts List	2
Install the Clik! Mobile Drive	4
Install the Clik! Mobile Drive to a Desktop Computer	5
Install the Clik! Mobile Drive to a Notebook Computer	10
Install the Clik! Mobile Drive to a Windows CE® Device	12
Install Your Software	14
Minimum System Requirements	14
Windows CE® Device Requirements	14
Software Installation	14
<i>Clik! Solutions</i>	17
Using Your Clik! Disks	18
Opening Clik! Disk Cases	18
Inserting and Ejecting Clik! Disks	18
Operating Conditions	18
Saving, Copying, Moving, and Deleting Files on Clik! Disks	19
Handling Clik! Disks	19
Understanding Clik! LED Lights	20

Using Your Clik! Mobile Drive with Your Digital Camera	21
Clik! Flash Memory Reader LCD	22
Using Your Clik! Mobile Drive with Your Notebook Computer	27
Saving, Copying, Moving, and Deleting Files on Clik! Disks	28
Printing and the Clik! Mobile Drive	28
Using Your Clik! Mobile Drive with Your Windows CE® Device	29
Saving, Copying, Moving, and Deleting Files on Clik! Disks	30
Using Your Clik! Batteries	31
Charging Your Clik! Batteries	31
General Charging Information	32
Storing Your Clik! Batteries	32
Disposing of Your Clik! Batteries	33
Using Clik! Software	34

<i>Accessories</i>	<i>37</i>
---------------------------------	------------------

<i>Help</i>	<i>41</i>
Troubleshooting	42
How to Get Help	48
Limited Warranty Information	51
Patent Information	52
Regulatory Agency Statements	53



Getting Started

Set up of your Clik! Mobile Drive can be easy and fast if you follow the directions below.

First, familiarize yourself with the names of the Clik! parts page 2

Second, attach the Clik! Mobile Drive to your computer using one of the following options:


  Install the Clik! Mobile Drive on a Desktop PC..... page 5

  Install the Clik! Mobile Drive on a Notebook PC..... page 10

  Install the Clik! Mobile Drive on a Windows CE[®] device page 12

Third, install the Clik! Software page 14

Klik! Drive Parts List




Klik! Mobile Drive

Attaches to your desktop PC via the Klik! Parallel Port Interface


Attaches to your notebook and handheld PCs via the Klik! PC Card Adapter and Interface Cable*

Attaches to the Klik! Flash Memory Reader**



Klik! Battery

Attaches to the Klik! Mobile Drive
Powers the Klik! Mobile Drive when Klik! Power Supply is not in use
Requires initial charging for first use



Klik! Desktop Dock

Charges the Klik! Battery (with Klik! Power Supply)

Holds the Klik! Mobile Drive on your desktop

Connects to the Klik! Parallel Port Interface



Klik! Parallel Port Interface

Connects to the Klik! Desktop Dock and a PC parallel port


Transfers data from the Klik! Mobile Drive to the PC

Acts as a pass-through device




Klik! Power Supply

Powers Klik! Mobile Drive when Klik! Battery is not in use



Klik! Flash Memory Reader*

Connects to the Klik! Mobile Drive
Copies image files from digital camera flash memory cards



Klik! PC Card Cable*

Connects the Klik! Mobile Drive to the Klik! PC Card Adapter*
Charges the Klik! Battery (with Klik! Power Supply)


Klik! PC Card Adapter*

Connects with a type II PC/MCIA card slot allowing data transfer from the Klik! Mobile Drive



Klik! Disk and Klik! Case

Disk stores up to 40 MB of data
Case protects the Klik! disk and should always be used to store your Klik! disks



Klik! Software Installation CD

Installs software for the Klik! Mobile Drive



Klik! User's Manual

Provides helpful installation instructions
Outlines common uses for the Klik! Mobile Drive and accessories



Klik! Quick Start Guide

Quick Reference Guide for setting up the Klik! Mobile Drive

**Klik! PC Card Adapter is not included in the Klik! Drive for Digital Cameras package.*

Install the Clik! Mobile Drive

The Clik! Mobile Drive can be used with a desktop PC, a notebook computer, and a Windows CE® device. Which instructions do you need?

☐

I want to use the Clik! Mobile Drive with a desktop PC.
Go to page 5.

☐

I want to use the Clik! Mobile Drive with a notebook computer.
Go to page 10.

☐

I want to use the Clik! Mobile Drive with a Windows CE® device.
Go to page 12.



Install the Clik! Mobile Drive to a Desktop Computer




Tips


- ◆ **Connect** the Clik! Parallel Port Interface **directly to** the parallel port on your computer.
- ◆ **Do not** connect the Clik! Parallel Port Interface to an A/B switch.
- ◆ **Do not** use parallel port dongles with the Clik! Mobile Drive.

Follow these instructions to connect the Clik! Mobile Drive to a desktop computer using the Clik! Parallel Port Interface and the Clik! Power Supply. (We give you instructions for attaching the battery so it will be ready to charge when you want to go mobile.)


Step 1: Attach the Clik! Battery to the Clik! Mobile Drive by sliding it onto the back of the Clik! drive until it snaps into place.



Step 2: Set the Clik! Mobile Drive (with Clik! Battery attached) into the Clik! Desktop Dock. The Clik! Mobile Drive will be facing forward when properly docked.




Step 3: Plug the Klik! Parallel Port Interface into the Klik! Desktop Dock.




Step 5: Shut off the power on the computer.


Caution: Always turn off power to the computer and all devices connected to it (such as printers or drives) before beginning any computer hardware change.




Step 4: Plug the Klik! Power Supply into the Klik! Parallel Port Interface. (Do not plug into an electrical outlet until step 10.)




Step 6: Locate the computer's parallel port. (You may have a printer or a scanner already connected to this port.)




Step 7: If you have a printer (or scanner) cable attached to this port, disconnect it.



Step 8: Connect the Klik! Parallel Port Cable to the computer's parallel port (connector fits only one way).




Step 9: If you have a printer (or scanner), connect the printer (or scanner) cable to the Klik! Parallel Port Interface. (The Klik! Parallel Port Interface acts as a pass-through device so that both the Klik! drive and your printer or scanner can use the parallel port.)




You should only connect a printer or a scanner to the Klik! Parallel Port Interface. For more information, see *Daisy Chaining Parallel Port Devices* on page 9.


Step 10: Plug in the Clik! Power Supply and then turn on the computer.



Step 11: Verify that the green power light on the front of the Clik! Desktop dock is on.



Step 12: Position the Clik! Desktop Dock AT LEAST 10 inches away from your computer monitor for best performance.



Step 13: Turn to *Install Your Software*, page 14, for software installation instructions.

After installing the software, you are ready to use the Clik! Mobile Drive with the Clik! Power Supply.

If you want to use the Clik! Drive with the Clik! Battery (without the Clik! Power Supply), the battery must be charged. Turn to page 31 for charging instructions.)

Note: The Klik! Mobile Drive can be inserted and removed from the Klik! Desktop Dock as needed. Power does not need to be turned off to insert the Klik! Mobile Drive.

Printers and Scanners **(Parallel Port Pass-Through Devices)**

The Klik! Parallel Port Interface operates as a pass-through device so that the printer (or scanner) and the Klik! Mobile Drive can share the parallel port. Sharing the port, however, means that you **cannot** print (or scan) while you are actively using the Klik! Mobile Drive (for example, copying files to and from the Klik! Mobile Drive).

If you experience initial problems using the pass-through printing feature of your Klik! Mobile Drive, see the *Troubleshooting* section for solutions.

Daisy Chaining Parallel Port Devices

You cannot connect numerous parallel port devices to each other. The maximum combination allowed is one pass-through device (a Klik! drive) and one printer or scanner. If you already have another pass-through device connected to the parallel port (for example, a Zip[®] drive), you will have to disconnect the Zip drive and connect the Klik! drive. When you want to use the Zip drive, you will have to disconnect the Klik! drive and connect the Zip drive.




Install the Klik! Mobile Drive to a Notebook Computer




Follow these instructions to connect the Klik! Mobile Drive to a notebook computer using the Klik! PC Card Adapter* and the Klik! Power Supply. (We give you instructions for attaching the battery so it will be ready to charge when you want to go mobile.)

Step 1: Attach the Klik! Battery to the Klik! Mobile Drive by sliding it onto the back of the Klik! drive until it snaps into place.




Step 2: Connect the Klik! PC Card Adapter cable to the Klik! Mobile Drive.




** The Klik! PC Card Adapter is not included in the Klik! Drive for Digital Cameras package. See Accessories section for purchasing information.*

Step 3: Plug the Klik! Power Supply into the Klik! PC Card Adapter cable and then into an electrical outlet.



Step 4: Slide the Klik! PC Card into the PC card slot. (Give it an extra push to make sure it is completely in the slot.)



Step 5: Turn to *Install Your Software*, page 14, for software installation instructions.

After installing the software, you are ready to use the Klik! Mobile Drive with the Klik! Power Supply.

If you want to use the Klik! Drive with the Klik! Battery (without the Klik! Power Supply), the battery must be charged. Turn to page 31 for charging instructions.

Note: The Klik! Mobile Drive **never** draws power from your notebook computer. It only draws power from the Klik! Battery or the Klik! Power Supply.




Install the Clik! Mobile Drive to a Windows CE[®] Device




Follow these instructions to connect the Clik! Mobile Drive to a Windows CE[®] device using the Clik! PC Card Adapter* and the Clik! Power Supply. (We give you instructions for attaching the battery so it will be ready to charge when you want to go mobile.)




Step 1: Attach the Clik! Battery to the Clik! Mobile Drive by sliding it onto the back of the Clik! drive until it snaps into place.




Step 2: Plug the Clik! PC Card Adapter cable into the Clik! Mobile Drive.



Step 4: Plug the Klik! Power Supply into the Klik! PC Card Cable and then into an electrical outlet.



Step 3: Slide the Klik! PC Card into the PC card slot. (Give it an extra push to make sure it is completely in the slot.)



Step 5: Attach your Windows CE[®] device to your host computer and install Klik! software. (See page 14 for software installation instructions.)

After installing the software, you are ready to use the Klik! Mobile Drive with the Klik! Power Supply.

If you want to use the Klik! Drive with the Klik! Battery (without the Klik! Power Supply), the battery must be charged. Turn to page 31 for charging instructions.

Note: The Klik! Mobile Drive **never** draws power from your Windows CE[®] device. It only draws power from the Klik! Battery or the Klik! Power Supply.



Install Your Software

Minimum System Requirements for the Klik! Mobile Drive

Windows® 95, Windows® 98, or Windows NT® 4.0 Workstation

16 MB RAM (Pentium processor recommended)

CD-ROM drive to install software

25 MB of free hard disk space

Standard parallel port for connection to PC* and/or Type II PC Card slot for connection to notebook**

Windows CE® Device Requirements**



Type II PC Card slot for connection

600k free space on the CE device

Windows CE® 1.0 or higher

* EPP capable parallel port recommended for maximum data transfer rate.

** Not required for the Klik! Drive for Digital Cameras package.

Software Installation

Important—Desktop PC Users: If you did not turn the power off when connecting the Klik! drive via the parallel port, restart your computer before installing the software. It is important that Windows recognizes the Klik! drive during software installation.

To install the Klik! software, insert the Klik! CD-ROM into your CD-ROM drive. The installation program will begin automatically. Click **Install Software** on the first screen to begin the installation process.

If the CD-ROM does not run automatically, choose Run from the Start menu, type X:INSTALL (where X is the letter of your CD-ROM drive) in the Open text box, and click OK.

No CD-ROM drive? If you want to install your Klik! drive on a computer that does not have a CD-ROM drive, refer to the information on page 16.

- 1 **License Agreement**—Read the license agreement and click Yes to accept it.
- 2 **Name and Company**—Enter your name and company name, then click Next.
- 3 **Type of Install**—Select the type of computer to which you have connected the Klik! drive:
 - ♦ *Desktop Computer*: Installs Klik! software and Iomega® Photo Printer to your desktop computer.
 - ♦ *Notebook*: Installs Klik! Software and Iomega Photo Printer to your notebook computer.
 - ♦ *Windows CE® Device*: Installs CE Tools to your Windows CE® device. (Be sure the device is attached to the host computer.)
 - ♦ *Custom*: Lets you choose all or one of the following: Klik! software, CE Tools, or Iomega Photo Printer.
- 4 **Destination Directory**—Click OK to accept the default directory which will be created for the Klik! software.
- 5 **Assign a Drive Letter**—It is necessary to assign a drive letter to your Klik! drive. This dialog box shows you all the drives your computer recognizes. Locate the Klik! drive—it will be called “removable disk”—and verify that an unused drive letter has been assigned. Click OK. (If installing the Klik! drive has caused your CD-ROM drive letter to change, you should change it back. This will prevent having to reinstall any applications or games you run from the CD-ROM drive.)

To change a drive letter, click the drop-down arrow next to it and select the drive letter you want to use. (The drive letter changes will not take effect until you reboot your system.)
- 6 **Registering Your Klik! Drive**—Take advantage of the on-line registration or use the registration card in the documentation packet.
- 7 **Restarting Your Computer**—After the software installation is complete, restart your computer. This ensures that all the necessary software is recognized by the computer.

No CD-ROM? If you do not have a CD-ROM drive, you can download software from the Iomega web site: Contact the Iomega Web site at <http://www.iomega.com> and click on **Software Download** to find the latest Iomega software package for your system.

Klik! Solutions

Using Your Klik! Disks and Klik! Mobile Drive page 18

Opening Klik! Disk Cases—Inserting and Ejecting Klik! Disks—Operating Conditions—Saving, Copying, Moving, and Deleting files on Klik! Disks—Handling Klik! Disks—Understanding Klik! LED Lights



Using Your Klik! Mobile Drive with Your Digital Camera and PC page 21

Copying Files From Your Digital Camera—Viewing Images on the Klik! Disk—Printing Images from the Klik! Disk



Using Your Klik! Mobile Drive with Your Notebook Computer page 27

Connecting the Klik! PC Card Adapter—Removing the Klik! PC Card Adapter—Saving, Copying, and Deleting Files—Printing and the Klik! Mobile Drive



Using Your Klik! Mobile Drive with Your Windows CE® Device page 29

Connecting the Klik! PC Card Adapter—Removing the Klik! PC Card Adapter—Saving, Copying, and Deleting Files—Printing and the Klik! Mobile Drive



Using Your Klik! Batteries page 31

Charging Your Klik! Batteries—General Charging Information—Storing Your Klik! Batteries—Disposing of Your Klik! Batteries





Using Klik! Software page 34

Using Your Click! Disks

Opening Click! Disk Cases

To open the Click! disk case, squeeze the top and bottom together as illustrated.



To eject the Click! disk from the Click! Mobile Drive, open the drive door, gently **push in** the Click! disk until it “clicks,” and then release it.



Caution: Never pull the disk out until it has been released by the drive. Never eject the Click! disk while the drive activity light is on. Never insert the disk backwards (black tabs first).

Inserting and Ejecting Click! Disks

The procedure for inserting and ejecting the Click! disk gives the Click! drive its name. Push in—“click-click”—and the disk is in. Push in again—“click”—and the disk pops out.

To insert the Click! disk into the Click! Mobile Drive, open the drive door and gently insert the disk (**label side up and rounded edge first**) until it “clicks” twice.

Operating Conditions


Let the Click! Mobile Drive and disks adjust to operating temperature (0° F to 120° F) before use. Do not operate the drive when condensation is present on the drive or disks. (Condensation usually occurs when moving from outside heat to inside air conditioning. If this is the case, wait a few minutes until the condensation evaporates.)

Saving, Copying, Moving, and Deleting Files on Klik! Disks

Klik! disks function as other diskettes when you want to copy, save, move, or delete files. After inserting the Klik! disk into the Klik! Mobile Drive, you can use all the Windows functions, e.g., save, copy, paste, drag and drop, delete.

With Windows® 95, Windows® 98, and Windows NT® 4.0, the Klik! drive appears as a drive letter (e.g., E:) under Explorer and My Computer.

(See page 30 for information regarding Windows CE® devices.)



Handling Klik! Disks

- ◆ Handle your Klik! disks with care.
- ◆ **Never** manually open the shutter of the Klik! disk. Opening the shutter of the Klik! disk manually could irreversibly damage the data on the disk.
- ◆ **Always** store and transport the Klik! disk in the Klik! case.
- ◆ **Never** transport the Klik! disk in the Klik! drive.
- ◆ **Never** apply additional labels to the Klik! disk. The additional thickness of even one label could cause damage to the Klik! drive.
- ◆ Use a soft touch when writing on the Klik! label. Pressing too hard with a writing instrument could damage data on the disk.



Understanding Klik! LED Lights


The **green** activity light on the Klik! Mobile Drive indicates the Klik! drive is reading or writing data.

The **green** activity light on the Klik! Desktop Dock appears when these two conditions are met: (1) you have inserted the Klik! Mobile Drive properly and (2) the Klik! Desktop Dock is receiving electrical power.

The light on the Klik! Battery serves three purposes:

- ♦ When the light is **green**, the battery is charging.
- ♦ When the light turns **off**, the battery has finished charging.
- ♦ When the light turns **amber**, the battery power is low; you have approximately four minutes of power remaining. Save all open files immediately and recharge the battery.

Note: The battery light will not display when the Klik! drive is in sleep mode.



Have you completed all the steps in the Getting Started section?



Using Your Klik! Mobile Drive with Your Digital Camera*

- ◆ **Set** your digital camera to save images in **JPEG** format rather than a camera-specific format. This will make using the copied files much easier.
- ◆ **Copying** files from the memory card to the Klik! Mobile Drive **does not** erase the image file from the card. Follow the digital camera's instructions for erasing these cards.
- ◆ The Klik! disk **must** have enough space available to accept **all** the memory card images in a single operation. If you do not have enough space on the Klik! disk to accept **all** the memory card images, **no** images will be copied and the LCD will display "nr". Insert a new Klik! disk and try again.




Tips

The Klik! Flash Memory Reader lets you copy the images from your digital camera's memory card to the Klik! disk.


To copy files from your digital camera:

Step 1: Verify the Klik! Battery is charged.

Step 2: Insert a Klik! disk into the Klik! Mobile Drive.




Step 2: Slide the Klik! Flash Memory Reader onto the Klik! Mobile Drive until it *snaps* into place.




Step 3: Remove the memory card from your digital camera.

Step 4: Insert the memory card (label side up) into the Klik! Flash Memory Reader.



Step 5: Press the button on the Klik! Flash Memory Reader to begin copying.



Do not insert a CompactFlashTM card and a Smart MediaTM card at the same time.

Step 6: Look at the LCD on the Klik! Flash Memory Reader.

- ♦ If you have enough space on the Klik! disk to accept **all** the images, the **arrows** on the LCD will move indicating that copying is in process.
- ♦ If you do not have enough space on the Klik! disk, the LCD will display "nr" (Not Enough Room). Insert a new Klik! disk.

Step 7: Remove the memory card from the Klik! Flash Memory Reader when copying is complete.

Note: Copying files from the memory card to the Klik! Mobile Drive will not erase the image files from the card. You will need to use your digital camera to erase the flash memory card.

Caution: Do not erase the memory card before verifying the files were copied onto the Klik! disk.

To identify icons on the LCD:



Flash Card Outline: Indicates no memory card inserted



Flash Card Icon: Indicates memory card inserted



Arrows (moving): Indicate transfer of data in progress



Klik! Disk Outline: Indicates no Klik! disk inserted



Klik! Disk Icon: Indicates Klik! disk inserted



Numeric display: Indicates percentage of space used on the Klik! disk. For example "60%" indicates the disk is 60% full, or that it has approximately 16 megabytes of disk space available.



nr: Indicates Not Enough Room on the Klik! disk to copy all files. Insert another Klik! disk. (Remember: If all the images cannot be copied onto the disk in a single operation, the Klik! Flash Memory Reader will ask for a new Klik! disk.)



bd: Indicates a Bad Disk. Insert another Klik! disk. Check the bad disk later. You may need to reformat it.



bc: Indicates a Bad Card. The Klik! Flash Memory Reader cannot read the inserted memory card.



2c: Indicates two memory cards are present. Remove one of the memory cards.


To make more than one copy of the contents of the memory card, remove the card and insert it into the Klik! Flash Memory Reader. This will reset the reader and copy the files again.

To locate the image files on the Klik! disk:

Step 1: Remove the Klik! Flash Memory Reader from the Klik! Mobile Drive by pressing in on the side buttons.

Step 2: Attach the Klik! Mobile Drive to your computer.

Step 3: Find the copied image files in a folder on the root level of the Klik! disk. (The root level of any drive is indicated by an alpha character, for example, D: or E:.) This folder will automatically be named "img00001" when the files are copied from the memory card. If "img00001" already exists on the Klik! disk, the folder will be named "img00002" and so on.



Note: The folder's creation date will be the date of the most recent image on the memory card.

To view images on the Klik! disk using Iomega® Photo Printer:

The image files copied to the Klik! disk will retain the file names assigned to them by the digital camera.

Step 1: Select Iomega Photo Printer from your Start Programs menu.


Step 2: Select the Photo Viewer tab.

Step 3: Select the disk containing the JPEG or bitmap files.

Step 4: Double-click on a photo.

Step 5: With a photo displayed, you can use your right and left arrow cursor keys to scroll through all the photos. To view the photos as a slide show, right-mouse click on the displayed photo and select Slide Show. The program will automatically scroll through all the photos on the disk.

Step 6: To return to the Photo Viewer tab, press the Esc key.



For more information on the Iomega Photo Printer software, see the on-line documentation.

To print images on the Klik! disk using Iomega® Photo Printer:

Step 1: Select Iomega Photo Printer from your Start Programs menu.


Step 2: Select the Photo Printer tab.

Step 3: Click on a photo.

Step 4: Select either Single Photo or Mixed Photos; then select the Photo Size. Note that the right-hand side of the window displays the photo and the changes as you select them.

Step 5: Click Print.

(If you are using the Klik! Parallel Port Interface as a pass-through device for your printer, Iomega Photo Printer must copy the image files to your hard drive. This may take several minutes.)



For more information on the Iomega Photo Printer software, see the on-line documentation.

To print images as thumbnails using Iomega® Photo Printer:

Step 1: Select Iomega Photo Printer from your Start Programs menu.

Step 2: Select the Thumbnail Printer tab.

Step 3: Select thumbnail size: small, medium, or large. Note that the Total Page count and the Preview box change as you make selections.

Step 4: Select High Quality Thumbnails only if you have the time to wait for them to print. (Higher quality=longer print time.)

Step 5: Click Print.

(If you are using the Klik! Parallel Port Interface as a pass-through device for your printer, Iomega Photo Printer must copy the image files to your hard drive. This may take several minutes.)





Using Your Clik! Mobile Drive with Your Notebook Computer




Tips

- ◆ The Clik! Mobile Drive **never** draws power from your notebook computer. It only draws power from the Clik! Battery or the Clik! Power Supply.
- ◆ When the Clik! Battery light turns **amber**, you have approximately **four minutes** to save your stuff before the Clik! Battery is depleted.

To connect the Clik! Mobile Drive to the notebook computer, provide power for the drive (use the Clik! Power Supply or the Clik! Battery), plug the Clik! PC Card Adapter cable* into the drive and slide the Clik! PC Card Adapter into the PC card slot. (Give it an extra push to make sure it is completely in the slot.) You may or may not see a message box stating "New Hardware Device Found." See page 28 for more information.

To remove the Clik! PC Card Adapter from your notebook computer, click on Start, select Settings, then Control Panel. Double-click on the PC Card icon. Highlight the IDE/ESDI Controller and click the Stop button. Eject the Clik! PC Card Adapter.

If you pull out the Clik! PC Card Adapter (or disconnect the drive from the card cable) without following the above instructions, your notebook may stop responding.



Have you completed all the steps in the Getting Started section?

Clik!
Solutions

**The Clik! PC Card Adapter is not included in the Clik! Drive for Digital Camera package. See Accessories section for purchasing information.*

Saving, Copying, Moving, and Deleting Files on Klik! Disks


Klik! disks function as other diskettes. After inserting the Klik! disk into the Klik! drive, you can use all the Windows functions, e.g., save, copy, paste, drag and drop, delete.

With Windows® 95, Windows® 98, and Windows NT® 4.0, the Klik! drive appears as a drive letter (e.g., E:\) under Explorer and My Computer.

Printing and the Klik! Mobile Drive

If you can print from your notebook, you can print files from your Klik! Mobile Drive while it is attached to your notebook via the Klik! PC Card Adapter.

Note: The first time you insert the Klik! PC Card Adapter, the "New Hardware Device Found" message may display. This message may not display again, depending on your operating system.





Using Your Klik! Mobile Drive with Your Windows CE® Device

- ◆ The Klik! Mobile Drive **never** draws power from your Windows CE® device. It only draws power from the Klik! Battery or the Klik! Power Supply.
- ◆ To use PC formatted files on your CE device, you **must** convert files to CE format **before** copying them to your Klik! disk.
- ◆ When the Klik! Battery light turns amber, you have approximately **four minutes** to **save** your stuff before the Klik! Battery is depleted.




Tips

All you have to do is attach your Klik! Mobile Drive to the Windows CE® device with the Klik! PC Card Adapter. Then you are ready to open, edit, save, copy, and move files as needed.

To connect the Klik! Mobile Drive to the Windows CE® device, provide power for the drive (use the Klik! Power Supply or the Klik! Battery), plug the Klik! PC Card Adapter cable* into the drive and slide the Klik! PC Card Adapter into the PC card slot. (Give it an extra push to make sure it is completely in the slot.)

To remove the Klik! PC Card Adapter, press the eject button and remove the card.



**The Klik! PC Card Adapter is not included in the Klik! Drive for Digital Camera package. See Accessories section for purchasing information.*

Have you completed all the steps in the Getting Started section?

**Klik!
Solutions**


Saving, Copying, Moving, and Deleting Files on Klik! Disks

You can save, copy, move, and delete files on the Klik! disks as you would normally with the Windows CE® device. Just remember that the Klik! Mobile Drive does not show in Windows Explorer or My Windows CE® device as a drive letter. It will display as a folder when you double-click on the My Windows CE® device icon.

- ◆ If you are using Windows CE® 1.0, the folder will automatically be named "PC Card."
- ◆ If you are using Windows CE® 2.0, the folder will automatically be named "Storage Card."

Klik! Software for Windows CE®

Klik! software for Windows CE® is different than the Klik! software for Windows 95/98. See the CE online documentation for instructions for using this software.





Using Your Clik! Batteries



Tips

- ◆ You **must charge** the Clik! Battery included with the drive **before** initial use.
- ◆ The Clik! Battery may not deliver its maximum capacity initially. You will receive maximum capacity after 3-5 cycles.

Charging Your Clik! Batteries


To charge your Clik! Battery using the **Clik! Desktop Dock**, set the Clik! Mobile Drive (with Clik! Battery attached) into the Clik! Desktop Dock.

Verify that the Clik! Parallel Port Interface cable is connected to the Clik! Desktop Dock.

Verify that the Clik! Power Supply is plugged into the Clik! parallel Port Interface and an electrical outlet.

Let the battery charge until the green battery light turns off (approximately 1.5 hours).

Your computer does not need to be on to charge the Clik! Battery.




To charge your Klik! Battery using the Klik! PC Card Adapter.* Attach the Klik! Battery to the Klik! Mobile Drive.

Verify that the Klik! PC Card Adapter cable is connected to the Klik! Mobile Drive.

Verify that the Klik! Power Supply is plugged into the Klik! PC Card Adapter cable and an electrical outlet.

Let the battery charge until the green battery light turns off.



General Battery Information

- ♦ Storing the Klik! Battery/Klik! Mobile Drive in the Klik! Desktop Dock for extended periods will not damage the battery. Not fully charging the battery will not damage the battery.
- ♦ Charging Klik! batteries in temperatures outside the range of 32° F to 104° F is not recommended.
- ♦ Using the Klik! batteries in temperatures outside the range 32° F to 120° F is not recommended.

Battery Life Expectancy

The Klik! Battery's life expectancy for 80% capacity or above is 500 charges/discharges.

Storing Your Klik! Batteries

- ♦ The Klik! Battery will lose its charge during storage if it is not kept in the Klik! Desktop Dock. It may lose 2% a day. This loss will increase if the battery is stored at higher temperatures.
- ♦ The Klik! Battery's life may be significantly reduced if stored in temperatures over 86° F for extended periods (weeks).
- ♦ The Klik! Battery's capacity will be significantly reduced after long-term storage. To restore capacity, charge and discharge the battery three to five times.

Disposing of Your Klik! Batteries

Your Klik! Battery is an NiMH battery. Improper disposal of this battery is unlawful. Contact your state, province, or country for the proper disposal procedures.

Using Klik! Software

Reformatting Klik! Disks

Klik! disks are sold preformatted and ready for immediate use. If you need to reformat a disk, however, follow the steps below.

Step 1: To reformat a disk, insert the Klik! disk into the Klik! drive.

Step 2: Right-mouse click on the Klik! drive icon in My Computer.

Step 3: Select Format from the drive shortcut menu.

Step 4: Choose the format type:

Use Quick Format if you want to quickly erase all data on a disk so you can reuse it.

Use Full Format if you are formatting a disk where you have forgotten the password, or if you need to repair a disk that has developed read/write errors due to bad sectors.

Step 5: Click Start to start formatting the Klik! disk.



***Caution:** Formatting a disk erases all data on the disk. Do not format any disk that contains information you want to keep!*

Iomega Photo Printer

Iomega Photo Printer lets you view and print JPEG and bitmap files from your Klik! drive. See pages 24-26 for instructions on viewing and printing images.


Accessories

This section highlights the Clik! accessories available for purchase.

Clik! Flash Memory Reader	page 38
Clik! PC Card Adapter	page 38
Clik! Parallel Port Interface	page 38
Clik! Desktop Dock	page 39
Clik! NiMH Rechargeable Battery	page 39
Clik! Power Supply	page 39


Klik! Flash Memory Reader

The Klik! Flash Memory Reader can copy images from memory cards of digital cameras to Klik! disks.




Klik! Desktop Dock

Just like the one that came with your drive, an additional desktop dock can be purchased so that you can have one at the office and at home.




Klik! PC Card Adapter

The Klik! PC Card Adapter (type II) lets you connect the Klik! Mobile Drive to a notebook computer or a Windows CE® device.




Klik! NiMH Rechargeable Battery

Just like the one that came with your drive, this rechargeable Klik! Battery can be purchased so that you have a spare battery.



Klik! Parallel Port Interface

The Klik! Parallel Port Interface lets you connect your Klik! Mobile Drive to the parallel port on your computer.



Klik! Power Supply

This power supply is the same as the one shipped with the Klik! Mobile Drive—you never know when you might need an extra one.



To order Klik! accessories, call 1-800-MY-STUFF. Prices and availability are subject to change without notice.

Help

Troubleshooting page 42

How to Get Help page 48

Limited Warranty Information page 51

Patent Information page 52

Regulatory Agency Statements page 53

Klik! Tips

- ♦ Use only Iomega Klik! power supplies and batteries with your Klik! drive. Other power supplies may damage your Klik! drive.
- ♦ Always turn on power to your computer before or at the same time as you supply power to your Klik! drive in the Klik! Desktop Dock. (Some computers have problems if a device connected to the parallel port receives power before the computer is turned on.) Iomega recommends using a power strip to turn on all your devices at the same time. Power must be applied to the Klik! drive before the operating system begins to load.
- ♦ Avoid exposing the Klik! drive or Klik! disks to dust, direct sunlight, high temperature, moisture, or magnetic fields (such as from monitors and some speakers).
- ♦ If you have a printer connected to the Klik! drive, make sure the Klik! Power Supply is connected to the Klik! Parallel Port Interface and plugged into an electrical outlet (even if you are not using the Klik! drive). Power to the drive is required for correct data pass-through to the printer.

Troubleshooting

If you encounter a problem while installing or using your Klik! drive, check this section for possible solutions. For additional help options, see *How to Get Help* on page 48.

The Klik! drive does not display under My Computer.

(a) Verify the drive is connected properly. (b) Verify the Klik! software has been installed.

The Klik! disk does not show 40 MB of space available.

Capacity of a Klik! disk reported by your operating system may vary depending on the system's method of megabyte calculation. (Iomega assumes 40 MB capacity where 1 MB = 1 million bytes.)

The Klik! disk will not accept any more files even though I seem to have plenty of space available.

(a) If you are trying to copy files from memory cards via the Klik! Flash Memory Reader, you may not have enough space on the Klik! disk to accept all the images. Insert a new Klik! disk and try again. *Note: some memory cards' capacities are larger than the Klik! disk capacity, e.g., 48 megabytes. You will not be able to copy 48 MB of memory card information onto a 40 MB Klik! disk.* (b) The maximum number of files allowed on the root directory of any disk is 512 (or less with Windows[®] 95, Windows[®] 98, and Windows NT[®] 4.0). The root directory of any drive is indicated by an alpha

character, for example, C: or D:. For the best performance of any drive, make other directories and subdirectories (e.g., C:\Iomega\Klik Images) and organize your files so that you never reach the maximum number.

“Device Not Ready” displays when I try to access the Klik! drive. Insert a Klik! disk into the Klik! drive and try again.

Troubleshooting for Parallel Port Connection

I connected my Zip drive, Klik! drive, and printer together, but nothing works. Connecting all three devices together is called daisy-chaining. The Klik! parallel port pass-through feature does not support daisy-chaining. The maximum combination allowed is one pass-through device (a Klik! drive **or** a Zip drive) and one printer **or** scanner. If you already have another pass-through device connected to the parallel port, you will have to disconnect it and connect the Klik! drive.

The Klik! drive is not assigned a drive letter. This could be due to a hardware installation problem or to a resource or software conflict on your computer system. The following suggestions will help you check your installation: (a) Turn off your computer and disconnect power from the Klik! drive. Turn on the computer first, then immediately connect the Klik! Power Supply (or use a power strip to turn on both your computer and your Klik! drive at the

same time). (b) Make sure that none of the pins on the Klik! Parallel Port Interface cable are bent and that the cable is connected properly. (c) Make sure the cable connections are straight and on all the way. Tighten all connector screws firmly and evenly. (d) Make sure the Klik! Parallel Port Interface cable is connected to a parallel port connection on the computer. This model of the Klik! drive will **NOT** work if it is connected to a serial port or a SCSI connection. (e) Try manually installing the Klik! parallel port driver using the Windows “Add New Hardware” wizard. (f) Try changing the parallel port mode on your computer. (See the manual that came with your computer for instructions.) If the computer still doesn't recognize the Klik! drive, the parallel port on the computer may not be compatible with the Klik! drive. Try installing the Klik! drive on a different computer. If a different computer recognizes the Klik! drive, the problem may be an incompatible parallel port. To solve this problem you need to add a new parallel port to your computer. If neither computer recognizes the Klik! drive, refer to How to Get Help on page 48.

Computer does not start up properly after installing Klik! drive. (Computer hangs on reboot or does not operate correctly.) Some computers will not start or operate correctly if a device connected to the parallel port receives power before the computer is turned on. Try the following:

(1) Turn off your computer and disconnect power from the Klik! drive. (2) Turn on the computer first, then immediately connect the Klik! Power Supply (or use a power strip to turn on both your computer and your Klik! drive at the same time). (3) Make sure the Klik! drive is seated in the Klik! Desktop Dock and that the green power light on the front of the Klik! Desktop Dock is on. If the computer still does not start correctly, the problem is probably due to a resource or software conflict on your computer system. Disconnect the Klik! drive from the computer and restart. Refer to the advanced troubleshooting information available on Iomega's web site (<http://www.iomega.com>) or through our Automated FAX-back help (1-801-778-5763).

The Klik! drive is assigned multiple drive letters.

Caution: Do NOT use the Klik! drive if it has been assigned multiple drive letters! Using a removable drive when multiple drive letters are present may result in data loss. Check our home page on the internet for solutions or call technical support for help with this problem.

Data transfer problems or drive operation is erratic.

(a) Make sure the Klik! Parallel Port Interface cable is correctly connected to both the Klik! Desktop Dock and the computer. (b) Make sure the Klik! drive is seated properly in the Klik! Desktop Dock. (c) Make sure all cable connections are straight and on all the way. Tighten the

connector screws firmly and evenly. (c) There may be a problem with the parallel port I/O card in your computer. Refer to the information in suggestions (f) on page 43.

Data transfer is slow. To improve data transfer performance, check the Parallel Port settings in your BIOS. (See your computer's documentation for information on changing the BIOS.) Select EPP, EPP 1.9, EPP 1.7, or ECP mode to enable the highest data transfer rate. If none of these choices are available, select PS2 or bi-directional mode. (Selecting Compatibility mode will cause the Klik! drive to operate at the slowest data rate.)

Troubleshooting with a scanner when it is connected to the Clik! parallel port pass-through connector.

Some scanners will not work correctly when connected to another parallel port device such as the Clik! drive. The compatibility issues are very similar to those described under Printer Troubleshooting for Windows[®] 95/98—problems result when scanner drivers are not designed to share the parallel port with another device in the Windows[®] 95/98 environment.

If you encounter problems with a scanner when it is connected to the Clik! parallel port pass-through device, first check the following: (a) Make sure the Clik! drive is correctly connected to the computer's parallel port connection. (b) Make sure all cable connections are straight and on all the way. If the problem continues, contact your scanner manufacturer for help. Updated scanner drivers that resolve the parallel port pass-through conflict may be available.

Printer Troubleshooting for Windows[®] 95/98

Important! Most solutions found in this guide will not allow you to use your Clik! drive and your printer at the same time if the printer is connected to the Clik! Parallel Port Interface. To print a file stored on a Clik! disk, you **MUST** copy it to another disk other than your Clik! disk (like a hard drive) and then print it.

Parallel Port Printer Pass-Through Solutions

Iomega has developed Windows[®] 95/98 compatible drivers for the Clik! drive. However, some printers will not work correctly when connected to other parallel port devices like the Clik! Parallel Port Interface. This section describes some possible solutions if you experience problems with your printer, but you should also contact your printer manufacturer; they know how to best address parallel port printer issues.

If you are experiencing any of the following problems . . .

- ♦ printer does not work when connected to the Clik! drive
- ♦ system stops responding (hangs)
- ♦ information gets lost during file transfer

. . . and you have one of the printers listed on the next page, try using one of the numbered solutions marked with an "X" for your printer.

	Solution	1	2	3	4	5
HP LaserJet 4s, 4+, 4v, 4si, and 4p		X				
HP LaserJet 5L					X	
HP LaserJet 5P, 5M, P, 6M, and DeskJet 600c			X			
HP LaserJet 4L				X		
HP LaserJet 4 and 6L						X
HP DeskJet 660CSE, 693C, 855c, and 870C						X
HP DeskJet 820c series*						
Lexmark				X		
Printer Not Listed						X

*There are currently no known software fixes for this printer. To use this printer with your Clik! drive you should install an additional parallel port.

Solution 1: Disable Status Monitor

The status monitor can usually be removed automatically with the following steps:

- 1 Click the Start button and select Run.
- 2 Type `C:\windows\dinstall -fdinstall.ins` and select OK.
- 3 Follow the instructions on the screen.
- 4 Shut down and restart Windows® 95/98.

If necessary, the status monitor can be removed manually by using the following steps:

- 1 Click the Start button and select RUN.
- 2 Type WIN.INI and select OK.

- 3 Locate the line `LOAD=HPSW.EXE` and place a semicolon (;) at the beginning of that line so that it reads: `;LOAD=HPSW.EXE`.

Note: If there are additional items on the `LOAD=` line, copy them and move them to a separate line. Note that the new line must begin with "`LOAD=`" in order to load the files correctly.

- 4 Save and exit the WIN.INI file and restart your computer.

Solution 2: Changing Printer Properties

You can use the program `HPPROPTY.EXE` to change your printer's properties and get your Clik! drive and printer working together; however, you will lose your printer's status monitor.

- 1 Before you access the Clik! drive, press `<Ctrl+Alt+Delete>`.
- 2 In the Task Manager select `HPPROPTY` and then select End Task.
- 3 Double-click My Computer and open the hard drive (usually the "C" drive).
- 4 Open the Windows folder and then the System folder.
- 5 Find and right-mouse click the file `HPPROPTY.EXE` and choose Rename.
- 6 Rename `HPPROPTY.EXE` to "`HPPROPTY.BAK`."

Solution 3: Turn off Bi-Directional Communication

If you are using Microsoft® print system drivers, you may be able to use the following procedure to disable bi-directional communication to the printer.

- 1 Double-click on My Computer.
- 2 Double-click on the Printers folder.
- 3 Right-mouse click the printer you are connecting to your Clik! drive and select Properties.
- 4 Click the Details tab.
- 5 Click on the button for Spool Settings (toward the bottom of the window).
- 6 Select "Disable bi-directional support for the printer."
- 7 Click OK.

The documentation that came with your printer may have detailed instructions on disabling bi-directional communication. If it does not and you are unable to disable bi-directional communication using the above procedure, contact your printer manufacturer for help.

Solution 4: Uninstall and Reinstall Printer Software

Uninstalling and reinstalling the printer drivers or the software that shipped with your printer while the printer is not connected may allow you to install the printer with the bi-directional mode disabled. Refer to the documentation that came with your printer for additional instructions.

- 1 Shut down your computer and disconnect power.
- 2 Disconnect your printer from the Clik! Parallel Port Interface.
- 3 Turn on your computer and let Windows® 95/98 load.
- 4 Click the Start button and select Programs; choose the HP LaserJet 5L folder and select Uninstall.
- 5 With the printer disconnected, reinstall printer software and select Install the PCL driver alternative.
- 6 Do not Restart Windows.
- 7 Shut down your system and turn off power.
- 8 Reconnect printer to the Clik! Parallel Port Interface.
- 9 Turn on your computer and let Windows 95/98 start.

Solution 5: Getting Help for Your Specific Printer

If your specific printer is not addressed in this manual and you are having trouble printing, please contact your printer manufacturer for the best way to resolve the printer pass-through conflict.

If you have an HP printer, contact the HP web site for information on fixes that are currently available. The HP web site address is <http://www.hp.com/cposupport/eschome.html>.

Over time, Iomega may have more information on your specific printer in the Iomega Automated FAX Help system (801-778-5763), or on the World Wide Web at www.iomega.com.

Printer Manufacturer Support

<u>Printer Manufacturer</u>	<u>Web Site Address</u>	<u>Technical Support</u>
Hewlett Packard	www.hp.com	(208) 323-2551
Canon	www.canon.com	(757) 413-2848
Lexmark	www.lexmark.com	(606) 232-3000
Okidata	www.okidata.com	(800) 862-5724
Brother	www.brother.com	(800) 276-7746

How to Get Help

Iomega's goal is to provide state-of-the-art support for its customers. Over time, our support options and pricing policies may change in light of evolving technology and global changes across the computer industry. This section of the manual contains information on the support options available at the time this manual was prepared. For up-to-date support information, contact Iomega's Home Page on the World Wide Web or call our automated FAX-back help system at 1-801-778-5763. **See page 50 for information about free One-on-One technical support for the Clik! Mobile Drive.**

Iomega's Home Page: <http://www.iomega.com>

If you have access to the Internet, Iomega's home page offers you advanced problem-solving support readily available 24 hours a day from a single Web site. Here's just some of what's available from our home page:

Download the latest Iomega software—The software that shipped with your drive may not be the most recent version. Choose Software Downloads from the Iomega Home Page to check for the most up-to-date Iomega software.

Diagnose and solve problems online—Use your Web browser to access individualized troubleshooting for all Iomega products. With a little information from you, the interactive troubleshooting system diagnoses your problem and guides you through a solution. It's like having a personal support technician available 24 hours a day!

Locate Iomega manuals—You can access an electronic copy of the manual for any Iomega product in PDF format. All you need to view and print the PDF file you select is the Acrobat Reader. If you don't already have the Acrobat Reader installed on your system, you can download it from Adobe's Web site: <http://www.adobe.com>.

Access online help pages—You can find help pages with answers to common questions (FAQs), troubleshooting or basic "how to" information. The help pages are in HTML format and can be viewed directly with your Web browser.

Automated Voice Technical Support:
1-800-879-7660*

This free, 24-hour support option lets you use a touch-tone phone to quickly and easily access prerecorded solutions to common problems. Just dial 1-800-879-7660* and the automated voice technical support system will guide you through a series of questions to an easy-to-follow solution.

Automated FAX-back Help:
(801) 778-5763 (U.S. & Canada)

Our FAX-back automated help system lets you use any touch-tone phone to instantly retrieve detailed support information to your FAX machine. When you call our FAX-back help number, you can order a catalog listing the FAX-back documents available for your Iomega product, or any document listed in the catalog. Just follow the voice instructions to order what you need.

*1-800-879-7660 is available in the U.S. and Canada.

**One-on-One Iomega Technical Support:
1-888-4-IOMEGA* (1-888-446-6342)**

If you don't have access to the Internet or a FAX machine and you have a problem you just can't resolve using our automated voice technical support system or the troubleshooting information in the manual, you can call one-on-one technical support for help. One-on-One technical support is provided free of charge only for 30 days from your first call during the warranty period. After that time, a charge of \$14.99 may apply. Technical support policies are subject to change at any time.

Before calling Iomega for technical support, turn on your computer and call from a phone at or near your computer. You may be asked to type commands at the keyboard or relay information about the system.

Iomega's highly trained technical support associates are ready to take your call Monday through Friday from 6 a.m. to 9 p.m. and Saturday from 7 a.m. to 2 p.m. (Mountain Time). Technical support hours are subject to change.

*1-888-4-IOMEGA is available in the U.S. and Canada.

Product Return or Repair

For information on returning your Clik! Mobile Drive or other Iomega product for warranty service (or repair after the warranty period), please call the Iomega Customer Satisfaction Hotline at 1-888-4-IOMEGA (1-888-446-6342). Because many returns are found to be due to a technical problem rather than a defective product, you may want to check with Iomega technical support before returning your drive—our trained support personnel can often resolve the problem over the phone.

Product Information

Call 1-800-MY-STUFF (1-800-697-8833) for information on new Iomega products, promotions, and rebates. You can also purchase Iomega products over the phone using your credit card (VISA, MasterCard, American Express, or Discover). Simply select the option of interest to you. See the Iomega web site for detailed product specifications.

International Support Numbers

For information on international customer support options and phone numbers, contact the Iomega Web site at <http://www.iomega.com>.

Limited Warranty Information

Coverage

Iomega® warrants this hardware product to be free from defects in materials and workmanship for the warranty period. This non-transferable, limited warranty is only to you, the first end-user Purchaser. The warranty begins on the date of purchase and lasts for the period specified below:

Clik!™, Zip®, Jaz® drives, Buz™ codec	one (1) year
Clik!™, Zip®, Jaz® disks	five (5) years
Ditto™ drive, Ditto™ tape cartridge	two (2) years
Any other Iomega® hardware product unless otherwise stated	one (1) year

Excluded Products and Problems

This warranty does not apply to: (a) Iomega software products; (b) expendable components such as fuses or bulbs; or (c) third party products, hardware or software, supplied with the warranted product. Iomega makes no

warranty of any kind on such products which, if included, are provided "AS IS." Excluded is damage caused by accident, misuse, abuse, unusually heavy use, use of non-Iomega supplied or approved media, or external environmental causes.

Remedies

Your sole and exclusive remedy for a covered defect is repair or replacement of the defective product, at Iomega's sole option and expense, and Iomega may use new or refurbished parts or products to do so. If Iomega is unable to repair or replace a defective product, your alternate exclusive remedy shall be a refund of the original purchase price.

The above is Iomega's entire obligation to you under this warranty. IN NO EVENT SHALL IOMEGA BE LIABLE FOR INDIRECT, INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, USE, OR PROFITS EVEN IF IOMEGA HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. In no event shall Iomega's liability exceed the original purchase price. Some states do not allow the inclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you.

Obtaining Warranty Service

You must notify Iomega[®] within the warranty period to receive warranty service. Information on warranty service is available toll free at 1-888-4-IOMEGA (446-6342). This number is the same as that used for Iomega's fee based technical support. Currently, for Klik! drive products, your warranty entitles you to free technical support. Iomega reserves the right to change this policy at any time and without notice.

If Iomega representative determines your Product is eligible for warranty service, you will be required to return it to Iomega, shipping prepaid, along with proper identification, a return authorization number provided by the representative, and proof of purchase. Iomega will not protect, recover, or return data during warranty service so you should duplicate your data before shipment.

Limitations

THE ABOVE WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. To the extent permitted by applicable law, IOMEGA SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Any implied warranty required by applicable law shall be limited in duration to

the express warrant term. Some states do not allow disclaimers of implied warranties or limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

This warranty gives you specific legal rights and you may also have other rights that vary from state to state. Any suit for breach of any warranty on your Product must be filed within one (1) year of the first date the suit could have been brought.

Patent Information

Protected by U.S. Patents 4,415,939, 5,444,444, and Patent applications pending in the U.S. and other countries.

Regulatory Agency Statements

United States FCC Information

The computer equipment described in this user's guide generates and used radio frequency (RF) energy. If the equipment is not installed and operated in strict accordance with the manufacturer's instructions, interference to radio and television reception may result.

Interference: This equipment complies with Part 15 of the FCC Rules and its operation is subject to the following conditions: (1) the equipment may not cause harmful interference, and (2) the equipment must accept any interference received, including interference that may cause undesired operation.

Part 15, Class B, of the FCC Rules, is designed to provide reasonable protection against radio and television interference in a residential installation. Although the equipment has been tested and found to comply with allowed RF emission limits, as specified in the above cited Rules, there is no guarantee that interference will not occur in a particular situation. Interference can be determined by turning the equipment off and on while monitoring radio or television reception. The user may be able to eliminate any interference by implementing one or more of the following measures:

- Reorient the affected device and/or its receiving antenna.
- Increase the distance between the affected device and the computer equipment.
- Plug the computer and its peripherals into a different branch circuit from that used by the affected device.

Warning: Only the manufacturer's cable or an equivalent double shielded, host interface cable should be used with external subsystems. Other types of cables may violate FCC rules and regulations. Also, changes or modifications to the electronics or enclosure of this product must be expressly approved by Iomega; otherwise, the user's authority to operating the equipment may be voided by the FCC.

Canadian Verification

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations (ICS-003, Class B).

UL Approval

In North America, this product is intended to be supplied with a UL-listed and Canadian certified Class 2 direct plug-in power unit, with a rated output of 5.0Vdc, 1.0A.

Manufacturer/Responsible Party

Iomega Corporation
1821 West Iomega Way
Roy, UT 84067 USA
801-778-1000

Index

A

- accessories 37
- assigning drive letters 15

B

- battery. *See* **Klik! Battery**

C

- cables 6
- Klik! Battery 2, 39
 - amber light indicates depletion 27
 - attaching to drive 5, 10, 12
 - disposal instructions 33
 - general information about 32
 - initial charging 31
 - LED lights 20
 - recharging 31
 - storing instructions 33

- Klik! Desktop Dock 2, 5
 - attaching to Klik! Parallel Port Interface 6
 - positioning with monitor 8
 - power light 8
- Klik! disk cases 18
- Klik! disks
 - ejecting/inserting 18
 - handling 19
- Klik! drive, activity light 20
- Klik! Flash Memory Reader 38
 - copies images to Klik! disk 22
 - digital cameras 21
 - inserting memory cards 22
- Klik! LED lights 20
- Klik! Mobile Drive 2
 - and Windows CE[®] device 29
- Klik! Parallel Port Interface 2
 - attaching to Klik! Desktop Dock 6
 - attaching to Klik! Power Supply 6
 - connecting to computer 7
- Klik! PC Card Adapter 38
 - connecting to notebook PC 11
 - connecting to Klik! drive 10, 12
 - connecting to Windows CE[®] device 13

Klik! Power Supply 2, 8, 39
 attaching to Klik! Parallel Port Interface 6
 codes, Klik! Flash Memory Reader 22
 CompactFlash™ 22
 copying data 19
 on notebook PC 28
 with Windows CE® device 30

D

daisy-chaining 9
 deleting data 19, 28
 with Windows CE® device 30
 desktop dock. *See* **Klik! Desktop Dock**
 Device Not Ready 43
 digital cameras
 Klik! Flash Memory Reader 21
 copying images from memory cards 22
 disks. *See* **Klik! disks**

E

ejecting disks 18

G

getting started 1

H

help, contacting Iomega 48

I

icons, Klik! Flash Memory Reader 22
 images, viewing on Klik! disk 24
 inserting disks 18
 installing Klik! drive
 with a Windows CE® device 12
 with notebook PC 10
 Installing software 8, 11, 14
 for Windows CE® device 13
 Iomega® Photo Printer 24

J

JPEG images 21

L

labels
 applied to disks 19
 writing on 19

M

memory reader. *See* **Klik! Flash Memory Reader**

N

- notebook computers
 - connecting Clik! PC Card Adapter 27
 - removing Clik! PC Card Adapter 27

O

- operating conditions 18

P

- parallel port interface. *See* **Clik! Parallel Port Interface**
- pass-through printing 7
- patents 52
- PC card adapter. *See* **Clik! PC Card Adapter**
- power supply. *See* **Clik! Power Supply**
- printers
 - connecting to Clik! Parallel Port Interface 7
 - troubleshooting 45
 - with pass-through devices 9
- printing 28

R

- registering Clik! drive 15

S

- saving data 19
 - from notebook PC 28
 - from Windows CE® device 30
- scanners 9
- SmartMedia™ 22
- system requirements 14

V

- viewing JPEG images 24

W

- warranty, limited 51
- Windows® 95 19, 28
- Windows® 98 28
- Windows CE® Device
 - connecting Clik! drive to 29
 - copying data 30
 - deleting data 30
 - removing Clik! drive from 29
 - saving data 30
- Windows NT® Workstation 19, 28